


# Home temperature logger



Metropolia University of applied sciences  
Smart systems, Virtual instrumentation  
project documentation  
Mikko Larke, 19.5.2020

## Key features

- Temperature logging for multiple rooms, outdoors and fridge/freezer
- User adjustable log file name and automatic polling rate
- Temperature visualisations over floorplan
- List of all temperatures for fast comparing
- Average temperature of indoors shown in trend
- Warning indicators when fridge/freezer temperatures are critical
- Visual representation of current time, timestamp of last reading and time left until next reading
- Every reading logged in formatted excel file
- Interactive UI
- Communication with MCU
- Can run two different programs from MCU
  - By default set to temperature readings and demo of fridge/freezer failure

## State functions

State	functions
Init	<ul style="list-style-type: none"> <li>• Initialize variables</li> <li>• Show startup config elements</li> <li>• Hide UI indicators</li> </ul>
Set_startup_config	<ul style="list-style-type: none"> <li>• Set name for log file, polling rate and serial port</li> <li>• Build file path for log file</li> </ul>
Check_startup_config	<ul style="list-style-type: none"> <li>• Check file path               <ul style="list-style-type: none"> <li>◦ Append to existing file or create new file</li> </ul> </li> <li>• Check valid serial port and time formats               <ul style="list-style-type: none"> <li>◦ Return to config and show warning if needed</li> </ul> </li> </ul>
Read_serial	<ul style="list-style-type: none"> <li>• Open and configure serial connection</li> <li>• Run one of configured UART modes</li> <li>• Show UI indicators</li> <li>• Hide startup config elements</li> </ul>
Check_serial	<ul style="list-style-type: none"> <li>• Check that received all readings from serial connection</li> <li>• If valid save readings to log file</li> <li>• Also appends trend array with new indoors average</li> <li>• If reading wasn't valid poll readings again</li> </ul>
Update	<ul style="list-style-type: none"> <li>• Update UI indicators with new readings.</li> <li>• Shown UI elements:               <ul style="list-style-type: none"> <li>◦ List of temperatures</li> <li>◦ Thermometers over floorplan</li> <li>◦ Indoors trend</li> <li>◦ Fridge/Freezer failure warnings</li> <li>◦ Demo mode indicator</li> </ul> </li> </ul>
Wait	<ul style="list-style-type: none"> <li>• Wait for next temperature reading</li> <li>• Show time until next reading</li> <li>• Get reading manually with button</li> <li>• Toggle UART mode</li> </ul>


## Uart mode functions

Uart mode	functions
Get temperatures	<ul style="list-style-type: none"> <li>• Send command to MCU for sending the temperature string</li> <li>• Read temperature string from MCU</li> <li>• Add timestamp to temperature string</li> <li>• Build 2 arrays from temperature string               <ul style="list-style-type: none"> <li>◦ String array for log file</li> <li>◦ Float array for UI</li> </ul> </li> <li>• Close serial connection</li> <li>• Change state tag for next state</li> </ul>
Activate demo mode	<ul style="list-style-type: none"> <li>• Send command to MCU for changing to fridge/freezer fail demo</li> <li>• Turn demo mode indicator led on/off</li> <li>• Close serial connection</li> <li>• Return to Read_serial state with get temperatures UART mode</li> </ul>

## Sub VI's functions

Sub VI	Functions
hsm_to_s	<ul style="list-style-type: none"> <li>• Takes in three integers (hour, minute and second)</li> <li>• Outputs hours, minutes and seconds converted to seconds</li> <li>• Range of each input is set to be valid (hour 0-23, seconds and minutes 0-59)</li> </ul>
FileExistence	<ul style="list-style-type: none"> <li>• Takes in file path</li> <li>• Checks if file exists in given path</li> <li>• If file doesn't exist vi creates that file</li> <li>• Vi also creates appropriate file header automatically</li> </ul>

## Flow chart



## C++ demo code

```
75 //Create base values of each temperature sensor according following formula:  
76 //<classname> <description>(<initial temperature>,<maximum change step>,  
77 //<minimum target temperature>,<maximum target temperature>  
78 ThermalData outdoors(15,0.9,-25,30);  
79 ThermalData kitchen(20,0.15,17,23);  
80 ThermalData bedroom(22,0.15,15,20);  
81 1 ThermalData livingroom(21,0.15,18,22);  
82 ThermalData bathroom(23.5,0.15,18,26);  
83 ThermalData fridge(4,0.01,3,6);  
84 ThermalData freezer(-17,0.01,-18,-15);  
85  
86  
87 //Randomizer seed taken from time  
88 srand(time(NULL));  
89  
90 int tempChangeCount=0; //When this reaches certain value temperature is changed  
91 int uartcode; //Code from labview to run correct code  
92 char buffer[256]; //buffer for character string containing temperatures  
93 bool demo=false; //keep track if fridge/freezer fail demo is on/off  
94  
95 while(1){  
96     tempChangeCount++;  
97     //Change temperature of each "sensor"  
98     if(tempChangeCount==500){  
99         outdoors.changeTemp();  
100         kitchen.changeTemp();  
101         bedroom.changeTemp();  
102         livingroom.changeTemp();  
103         bathroom.changeTemp();  
104         fridge.changeTemp();  
105         freezer.changeTemp();  
106         tempChangeCount=0;  
107     }  
108  
109     //Parse temperatures to one string  
110     sprintf(buffer,256,"%2f;%2f;%2f;%2f;%2f;%2f\n",  
111         outdoors.getTemp(),kitchen.getTemp(),bedroom.getTemp(),  
112         livingroom.getTemp(),bathroom.getTemp(),fridge.getTemp(),freezer.getTemp());  
113     3  
114  
115     //Read UART code from VI  
116     uartcode = Board_UARTGetChar();  
117     switch(uartcode){  
118         //get temperatures  
119         case '1':  
120             //Send parsed string via UART  
121             Board_UARTPutSTR(buffer);  
122             ITM_write("String sent to VI\n");  
123             break;  
124             //turn fridge/freezer fail demo on/off  
125         case '2':  
126             if(!demo){  
127                 fridge.setTemp(15);  
128                 freezer.setTemp(5.27);  
129                 demo=true;  
130                 ITM_write("Demo on\n");  
131             }  
132             else {  
133                 fridge.setTemp(4);  
134                 freezer.setTemp(-17);  
135                 demo=false;  
136                 ITM_write("Demo off\n");  
137             }  
138             break;  
139             //Show temperature string in console for testing  
140         default: //  
141             if(tempChangeCount==0){  
142                 ITM_write(buffer);  
143             }  
144         }  
145     }  
146     //Sleep for 10ms  
147     sleep(10);  
148 }
```

```
12  
13 class ThermalData {  
14 public:  
15     ThermalData(float temp_in, float step_in, float minTemp_in, float maxTemp_in);  
16     virtual ~ThermalData(){};  
17     float changeTemp();  
18     float getTemp(){return temp;}  
19     void setTemp(float newTemp);  
20  
21 private:  
22     float temp;  
23     float step;  
24     float maxTemp;  
25     float minTemp;  
26 };  
27  
28  
29 ThermalData::ThermalData(float temp_in, float step_in, float minTemp_in, float maxTemp_in){  
30     temp=temp_in;  
31     step=step_in;  
32     maxTemp=maxTemp_in;  
33     minTemp=minTemp_in;  
34 }  
35  
36 float ThermalData::changeTemp(){  
37     float min,max;  
38     if(temp <= minTemp){  
39         min=0;  
40         max=step*10;  
41     }  
42     else if(temp >= maxTemp){  
43         min=-step*10;  
44         max=0;  
45     }  
46     else{  
47         min=-step;  
48         max=step;  
49     }  
50     float random = ((float) rand()) / (float) RAND_MAX;  
51     float range = max - min;  
52     temp+= (random*range) + min;  
53     return temp;  
54 }  
55  
56 void ThermalData::setTemp(float newTemp){  
57     temp=newTemp;  
58 }
```

1. Initialize each demo sensor with starting temperature, step size of change and range of target temperatures
2. Change temperature of each sensor every 5 seconds (500\*10ms)
3. parse temperature string from last sensor values
4. Code has 2 modes set by UART code send by VI, which is select by switch case.
  - 4.1. Send temperature string to VI by UART
  - 4.2. Turn fridge/freezer failure demo on/off
5. Temperature change is simulated by getting random float between negative and positive step size. If temperature exceeds set temperature range temperatures only approach values within the range

## Features to be added

- Compatibility with more than 2 UART modes
- Ability to change file and polling rate without restarting program
- Ability to set polling rate greater than 24 hours
- Option for users to append indoors trend from log file
- Option for users to change how many readings trend shows at time